

72IN STAINLESS STEEL TOOL CHEST REPAIR KIT

Costco Item No 496675



Just inside the right cabinet door, there is a metal flange that runs vertically from top to bottom, which acts as the stop for the door. This flange may have a sharp edge and, under the right conditions, could result in injury should someone contact the sharp edge when moving items in and out of the tool chest. This repair kit will allow the consumer to place a protective strip over this sharp edge.

Required for this Repair Kit:

- neoprene strip
- lock plate
- Glue
- Philips screwdriver (not included)



Installation Instructions:

1. Open the right door of the Tool Chest and ensure there is enough space around the door stopper to be able to install the repair kit. Using the provided glue, place multiple beads of the Super glue down the length of the right edge of the door stopper frame prior to installing the neoprene strip. This glue will ensure that the strip remains in place.

Note: It is recommended that the drawer be emptied while the repair work is done, and can be re-filled once the fix is in place.

*Note: Prior to use, please review the **Super Glue Directions & Warning** at the end of this document.*



2. Assemble the black neoprene strip onto the door stopper. Starting at the bottom and with the straight edge of the strip facing downward, push the neoprene strip by hand onto the metal edge of the door stopper and work your way vertically until the entire edge is covered.

Note: Wipe away any excess glue that seeps out from the strip with a damp cloth.



3. Try to lock and unlock the door. If the door can be locked (the lock signal shows **Red**) and unlocked (the lock signal shows **Green**) smoothly, the repair is complete. If the door cannot be locked and unlocked smoothly, follow Step 4.



Unlocked (lock signal is **Green**)



Locked (lock signal is **Red**)

4. Using a Philips screwdriver (not included), loosen and remove the bolt and washer from the back of the lock, and take out the original lock plate, as shown. Discard the original lock plate, and save the bolt and washer for reuse in Step 5.



5. Keeping the lock unlocked (the lock signal is **Green**), place the lock plate on the back of the lock so that it points up and bends away from the door (middle picture below). Place the washer on the bolt and then install the bolt into the back of the lock.



6. If the door can now be locked and unlocked smoothly, the repair is complete. If you still continue to have issues, please contact Whalen Customer Service at (866) 942-5362 or send an email to support@whalenstorage.com.

Super Glue Directions & Warning

SUPER GLUE LIQUID

Use for gluing smooth and close fitting surfaces.

DIRECTIONS:

1. Protect area and clothing from accidental drips and spills.
2. Tube seal must be punctured before using.
 - Unscrew the Cap and Nozzle assembly.
 - Point tube away from face and body.
 - Pierce tube seal with point on top of cap.
 - **DO NOT SQUEEZE TUBE WHILE PUNCTURING.**
3. Replace Cap and Nozzle assembly by screwing clockwise onto tube.
4. Ensure surfaces to be bonded are clean, dry and close fitting.
5. Apply glue to one surface only. Use sparingly.
6. **DO NOT** spread glue with finger as skin bonding will occur.
7. Press surfaces together and hold for 30 seconds.
8. Replace cap by turning clockwise onto nozzle.
9. Store in cool / dry place.

NOTE: Do not use on polyethylene and polypropylene plastics; glass and glassware; foam rubber, or cloth.

WARNING: Contains Cyanoacrylate. May cause allergic skin reaction. Skin contact through clothing may cause burns. Avoid contact with skin and eyes. **FIRST AID:** In case of eye contact, flush with water for 15 minutes; call a physician. For skin contact, flush with water. For ingestion, do not induce vomiting; call a physician. If spilled on clothing, flush with large quantities of water. **KEEP OUT OF THE REACH OF CHILDREN.**

Henkel Corporation
Rocky Hill, CT 06067

Made in China

©Henkel Corporation 2010/41687



4 PACK

**12 TOTAL
GRAMS**

SUPER GLUE

Quick Bonding • Glues Most Materials

WARNING: EYE AND RESPIRATORY IRRITANT BONDS TO SKIN IN SECONDS. See back panel.



4 TUBES .11 OZ (3g) EACH TOTAL NET WT .44 OZ (12g)